



Start and Go



1. Sit down in the FUV, press the brake pedal and **fasten the seat belts**.



2. Set the Direction switch on the right grip to **Neutral** (•).



3. Insert the key and turn it to the **ON** position.



4. **With the brake pedal firmly depressed**, press the **START** trigger on the left grip to start the FUV.



5. Press the Parking Brake button on the Control Panel to **release the Parking Brake**. The Parking Brake is fully released when all three LEDs on the button are off (approximately three seconds).



6. Set the Direction switch to **Forward** (↑).




7. **Gently** twist the throttle to go!

Parking and Shut Down



1. Find a safe spot to park, and bring the FUV to a complete stop. **Leave the brake pedal depressed.**



2. Slide the Direction switch to **Neutral (•)**.



3. Press the Parking Brake button on the Control Panel to **engage the Parking Brake**. The Parking Brake is fully engaged when all 3 LEDs on the button are lit (approx 3 secs).



4. Turn the Key to **OFF** and remove the Key.



5. Release the brake pedal.

*Read the **FUV Owner's Guide** for details on safely operating the FUV and on using all of the features and functions. Follow all safety notes and warnings, always wear seat belts, and obey all local traffic laws.*

Customer Support	Contact Information
Roadside Assistance / Customer Support: (541) 780-0032	2034 W. 2nd Ave. Eugene, OR 97402 (541) 683-6293 info@arcimoto.com

© 2019 Arcimoto. All rights reserved. All information contained within this publication is based on the latest product information available at the time of publication. Product improvements or other changes may result in differences between this Guide and the vehicle. Arcimoto® and FUV® are trademarks of Arcimoto, Inc.